

ITEM CODE: 01803

TOOLS REQUIRED:

Philip's head screwdriver,
Stud finder, Electric Drill,
Rubber Mallet, Pencil, Spirit Level

WARNING: HANDLE CUT METAL
EDGES CAREFULLY

PARTS LIST



⚠ IMPORTANT NOTE

Total weight loading for the Rack It Wall 900mm Starter Kit **must not exceed 100KG** each, including items loaded onto hooks and other accessories. Adding such accessories does not increase weight loading capacity.

STEP 1

Find and mark at least two studs on chosen wall using Stud Finder.



STEP 2

Place Hang Track onto wall and use a Spirit Level to ensure Hang Track is level. Then Mark all screw positions with pencil.




STEP 3

Insert Plasterboard Anchors into required locations by pushing them into the plasterboard and tightening with a screwdriver.



STEP 4


Secure Hang Track to wall by inserting provided screws through Hang Track screw holes and into Plasterboard Anchors. Use an electric drill to screw into studs.



STEP 5

Hang Wall Strip onto one end of the Hang Track.

Note: Wall Strip is not secured to wall at this point.



STEP 6

Repeat step 5 for second Hang Track



STEP 7

Attach back beam to both wall strips at desired height




STEP 8

Tap in place with mallet to ensure proper fit




STEP 9

Mark Wall Strip screw points on to wall with pencil.

**STEP 10**

Remove Wall Strips from Hang Track and insert Plasterboard Anchors into required locations by pushing them into the plaster board and tightening with screwdriver.

**STEP 11**

Place wall Strips back on to Hang Track, along with Back Beam ensuring the Wall Strips line up with Plasterboard Anchors from Step 10.

**STEP 12**

Screw provided screws into Plasterboard Anchors to secure both Wall Strips.

**STEP 13**

Attach Brackets to Wall Strip so that the top of the Bracket is in-line with Back Beam.

**STEP 14**

Repeat step 13

**STEP 15**

Tap Brackets into place with a mallet.

**STEP 16**

Attach Front Beam to Brackets.

**STEP 17**

Tap Front Beam into place with mallet.

**STEP 18**

Insert Support Braces into Front and Back Beams in the two matching slots on both Beams.

**STEP 19**

With self tapping screws provided, screw into designated position.

**STEP 20**

Place wire shelf provided onto Beams and Support Braces.

